

TOUCHLESS SENSOR

ELE-1001-01-xx



Compatible with:

KITCHEN FAUCET

WITH PULL-DOWN SPRAY

CUI-1940-02L
CUI-2040-02L
CUI-2040-35L
CUI-9245-02L
CUI-9246-02L
CUI-9247-02L
CUI-9248-02L
CUI-9249-X2L
CUI-9250-X2L
CUI-9335-02L
CUI-9340-02L
CUI-9345-02L
CUI-9350-02L
CUI-9352-02L
CUI-9355-02L
CUI-9540-35L

ELE-2001-01-xx



Compatible with:

KITCHEN FAUCET

LAVATORY FAUCET

WITHOUT PULL-DOWN SPRAY	SINGLE-HOLE	WALL-MOUNTED	DECK-MOUNTED
CUI-2030-02L-xx	B04-1005-XXL-xx	B04-8100-00L-xx	B04-8009-00L-xx
CUI-9181-47L-xx	B04-1020-00L-xx	B04-8120-00L-xx	B05-8009-00L-xx
CUI-9380-02L-xx	B05-1005-XXL-xx	B05-8100-00L-xx	B14-8009-00L-xx
	B05-1010-XXL-xx	B16-8041-00L-xx	B16-8001-01L-xx
	B05-1015-XXL-xx	B18-8041-00L-xx	B18-8001-00L-xx
	B05-1020-00L-xx	B35-8100-00L-xxxx	B26-8000-00L-CD
	B14-1010-XXL-xx	B45-8100-04L-xx	B27-8000-00L-xx
	B14-1020-00L-xx	B46-8100-04L-xx	B28-8000-00L-xx
	B45-1005-XXL-xx	B47-8100-00L-xx	B35-1020-00L-xKx
	B45-1010-XXL-xx	B51-8100-00L-xx	B35-8009-00L-xxxx
	B45-1020-00L-xx	B66-8100-02L-xx	B45-8009-00L-xx
	B46-1010-XXL-xx	B66-8100-04L-xx	B46-8009-00L-xx
	B46-1020-00L-xx	B66-8120-04L-xx	B47-1080-00L-xx
	B46-1030-XXL-xx	B71-8041-00L-xx	B47-8009-00L-xx
	B46-1035-00L-xx	B72-8041-00L-xx	B56-8009-00L-xx
	B46-1040-00L-xx	B74-8041-00L-xx	B66-8009-00L-xx
	B51-1010-XXL-xx	B80-8042-00L-xx	B66-8029-00L-xx
	B56-1010-XXL-xx	B80-8102-00L-xx	B71-8001-01L-xx
	B66-1005-XXL-xx		B72-8001-01L-xx
	B66-1010-XXL-xx		B80-8001-1PL-xx
	B66-1020-00L-xx		B80-8002-1PL-xx
	B66-1030-00L-xx		B80-8003-1PL-xx
	B80-1031-XXL-xx		
	B80-1032-XXL-xx		
	MON-2600-00L-xx		